

TPLQ-2



Soil Sampler Kits

Introduction



INNOVA BIOMED INSTRUMENTS LIMITED
Add: Lucky centre, 165 Wanchai Road, Wanchai, Hong Kong
Qingdao Innova Bio-Meditech Co., Ltd.
Add: No. 1022 Beilao Road, Licang district, Qingdao, China
Tel.: 0086-532-8789 0634
Email: info@innobiomed.com

TPLQ-2 Soil Sampling Kit is one of the necessary instruments for testing the physical and chemical properties of soil sampling! It contains a full set of soil sampler accessories, after assembly can be used for loose soil area drilling 1-2 meters of disturbed soil in soft soil areas. The use of the soil sampling kit not only reduces the workload of soil investigation and improves the efficiency of soil sampling, but also extends the adaptability of soil sampling.

Features

- The whole is made of stainless steel 304, which will not pollute the soil sample.
- The material is hard and the shape is not easy to be bent and twisted.
- Spiral cutter makes taking soil more convenient, fast and labor-saving, reducing labor intensity.
- It can take 15~20cm of soil each time.
- Soil sampling toolbox exterior is marked with a scale value, each grid scale is 100mm, for taking soil samples of different depths to provide reference.
- The soil sampling head is threaded with the receiver and handle, which does not take up any volume after disassembly and is easy to transport
- When need to measure soil moisture data, it can be used as the connection rod of soil moisture sensor.
- The depth of soil extraction is 1m, 1.5m, 2m.



INNOVA BIOMED INSTRUMENTS LIMITED
Add: Lucky centre, 165 Wanchai Road, Wanchai, Hong Kong
Qingdao Innova Bio-Meditech Co., Ltd.
Add: No.1022 Beilao Road, Licang district, Qingdao, China
Tel.: 0086-532-8789 0634
Email: info@innobiomed.com

Packing list

Name	Specification	QTY
Manual	—	1
Soil head	—	1
Connector tube	—	2
Lengthen connector tube	—	2
Handle	—	1
Scraper	—	1
Wrench	24*22	2
Brush	—	1
Tape measure	3m	1